101 Djembe 1 Twin-Djembe+Perc

D-BEAM Tree Chime



Kick pad
Ankle Bells

Hi-hat pedal
Afro Claves

102 Djembe 2 Djembe+Perc

D-BEAM Bell Tree



Kick pad
Ankle Bells

Hi-hat pedal
Afro Claves

103 Conga 1 Conga II+Perc

D-BEAM Tree Chime



Kick pad
Compact Kick

Hi-hat pedal
Claves 1

104 Conga 2 Conga Trio+Perc

D-BEAM Latin Crash



Kick pad
Floor Tom Kick

Hi-hat pedal
Cowbell 4

105 Bongo 1 Bongo+Perc

D-BEAM Tree Chime



Kick pad
Claves 1

Hi-hat pedal
Claves 2

106 Bongo 2 Conga&Bongo+Perc

D-BEAM Latin Crash



Kick pad
Pandeiro Thumb
+ Riq Jingle

Hi-hat pedal
Claves 2

107 Unplugged Cajon+Perc

D-BEAM Tree Chime



Kick pad
Cajon Foot

Hi-hat pedal
Tamb. 1

108 Rock Hands Two-Snare Rock

D-BEAM Wild Crash



Kick pad
Close Miked Kick

Hi-hat pedal
Dark HH Pedal

109 Pop Kit+ Pop Drums+Tamb

D-BEAM Ambient Crash



Kick pad
Mellow Kick

Hi-hat pedal
Dark HH Pedal

110 Band Perc Conga+Perc

D-BEAM Suspended Crash



Kick pad
Compact Kick

Hi-hat pedal
Metal Maracas 2
+ Metal Maracas 2

111 Djembe Pop Djembe+Claps

D-BEAM Tree Chime



Kick pad
Djembe Lo Bass
+ Vintage Kick

Hi-hat pedal
Shaker 1

112 Djembe Rock Djembe+Kit

D-BEAM Wild Crash



Kick pad
Djembe Lo Bass
+ Plugged Kick

Hi-hat pedal
Light HH Pedal

113 Rock Perc Congas+Tamb

D-BEAM Suspended Crash



Kick pad
Tamb. 2

Hi-hat pedal
Shaker 2

114 Pop Perc Bongos+Shaker

D-BEAM Tree Chime



Kick pad
Tamb. 2

Hi-hat pedal
Shaker 2

115 Latin Rock Congas+Timbales

D-BEAM Tree Chime



Kick pad
Cowbell 4

Hi-hat pedal
Shaker 2

116 Ballad Perc Frame Drum+Bells

D-BEAM Tree Chime



Kick pad
Tamb. 2

Hi-hat pedal
Shaker 2

117 Funk Perc Congas+Guiro

D-BEAM Thin Crash



Kick pad
Tamb. 2

Hi-hat pedal
Shaker 2

118 Reggae Island Perc

D-BEAM Tree Chime



Kick pad
Cross Stick 2

Hi-hat pedal
Shaker 2

119 Worship Acoustic Church

D-BEAM Suspended Crash



Kick pad
Frame Drum L

Hi-hat pedal
Tamb. 2

120 Samba Brazilian Perc

D-BEAM Latin Crash



Kick pad
Surdo

Hi-hat pedal
Ganza 2

121 Middle East Darbuka+Riq

D-BEAM Bell Tree



Kick pad
Frame Drum L

Hi-hat pedal
Riq Jingle

122 Steel Pan C C Major + Bass

D-BEAM Tree Chime



Kick pad
Shaker 1

Hi-hat pedal
Tamb. 2

123 Kalimba Am A Min Pentatonic

D-BEAM Tree Chime



Kick pad
Caxixi 1

Hi-hat pedal
Shaker 1

124 Shaker Perc Shakers+Tamb+Tri

D-BEAM Rain Stick



Kick pad
Tamb. 2

Hi-hat pedal
Shaker 2

How to read this

Each circle is the HPD-20's playing surface, seen from where you sit: **S1–S8** around the top edge, **M3/M4** inside them, **M5** in the center and **M1/M2** the bottom halves.

hard: a second sound for hard hits (play soft for the first).
+ a second sound layered under the first.
Notes in bold are the pitch a melodic pad plays.
★ your own imported sounds (User Inst).

D-BEAM (above each circle): wave a hand over the sensor. The **kick pad** plugs into TRIG IN, the **hi-hat pedal** into HH CTRL.

Free HPD-20 kits 101–124 from hpd20editor.com · made with hpd20editor.com